


## ST150 MoldCALIPER – Mold Width Set-up Gauge



**Figure 1:** This gauge enables the narrow faces to be positioned within 0.004 inch to Setpoint (at the bottom or top of the coppers). Shown here is the 7-foot model for use on mold widths up to 76" wide. The gauge may be sized to fit any mold opening. The adjustable end feet allow the unit to sit level on practically any uneven surface. The gauge may also be used to verify taper.



**Figure 2:** A precision level is mounted to the top of the gauge to level the unit on the mold. The carriage swivels about the end feet; this enables a reference to the center of the broad faces, resulting in +/- values for the half widths.

